# **LED Dimmer**

UV1-B a010083

Rotary dimming / Numeric display / Wireless Remote Control / Seven PWM frequency / Multiple protection

### **Features**

- Dual knob constant voltage LED dimmer with digital display.
- Rotate knob to change brightness and breathing fade speed.
- $\bullet$  Match with RF 2.4G single zone or multiple zone dimming remote control optional.
- 0-100% dimming smoothly without any flash.
- High load current up to 20A.
- PWM frequency 250Hz, 500Hz, 1KHz, 2KHz, 4KHz, 8kHz or 16kHz selectable.
- Over-heat /Short circuit protection, recover automatically.






C€ RoHS emc RED


# **Technical Parameters**

Input and Output		Dimming data			
Input voltage	12-24VDC	Input signal	Knob + RF 2.4GHz		
Input current	20.5A	Control distance	30m(Barrier-free space		
Output voltage	12-24VDC	Dimming gray scale	4096 (2^12) level		
Output current	20A@250/500/2KHz	Dimming range	0-100%		
	15A@4K/8KHz 10A@16KHz	Dimming curve	logarithm		
Output power	240-480W@250/500/2KHz	PWM Frequency	2KHz (default)		
	180-360W@4K/8KHz 144-288W@16KHz	Warranty&Protection			
Environment		Warranty	5 years		
Operation temperature	Ta: -30°C ~ +50°C	Protection	Reverse polarity Over-heat Short circuit		
Case temperature (Max.)	Tc: +85°C	TOEGION			


Safety and EMC							
	ETSI EN 301 489-1 V2.2.3						
EMC standard (EMC)	ETSI EN 301 489-17 V3.2.4						
Safety standard	EN 62368-1:2020+A11:2020						
Radio Equipment(RED)	ETSI EN 300 328 V2.2.2						
Certification	CE,EMC,RED						
Package							
Size	L100 x W46 x H38mm						
Gross weight	0.092kg						

### Mechanical Structures and Installations





# Wiring Diagram





### **Knob Function**



Bright: 1-100%

Brightness knob: rotate knob to adjust 1-100% brightness. When turn off light, display OFF.





Speed knob: rotate knob to adjust breathing fade speed, 10 level, display P01-P10, P10 is the fastest speed.



Breathing fade mode speed, i.e. 1%-100%-1% fade time:

No.	PO 1	PO2	PO3	P04	PO5	P06	P07	P08	P09	P10
fade time	60S	30S	20S	108	85	6S	4S	3S	2S	18

#### Note:

- 1. When adjusting the brightness by brightness knob or remote control will exit the breathing fade mode.
- 2. When display OLA, overload alarm. When display OHA, overheat alarm.

# **PWM Frequency Setting**

- Push twice Match key fastly, enter PWM frequency setting state, then rotary speed knob to select seven PWM frequency: 250Hz(F02), 500Hz(F05), 1KHz(F10), 2KHz(F20), 4KHz(F40), 8KHz(F80) or 16KHz(F16). Rotary brightness knob or timeout 10 seconds, automatically exit PWM frequency setting state.
- Higher PWM frequency, will cause lower output current, higher power noise, but more suitable for camera(No flickers for video).
- Default PWM frequency: 2KHz.

# Match Remote Control (Optional)

End user can choose the suitable match/delete ways. Two options are offered for selection:

#### Use Match key


#### Match:

Short press match key, display "RLS", immediately press on/off key (single zone remote) or zone key (multiple zone remote) on the remote. Display"RLO" means match is successful.

## Delete:

Long press match key for 5s to delete all match. Display"RLE" means all matched remotes were deleted.

#### 1 /



### Use Power Restart

#### Match:

Switch off the power, then switch on power, repeat again. Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. Display "RLO" means match is successful.

# Delete:

Switch off the power, then switch on power, repeat again. Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote. Display "RLE" means all matched remotes were deleted.

### Installation Precautions

- 1. The products shall not be stacked, the distance should be ≥ 20cm, so as not to affect lifespan of the products due to poor heat dissipation.
- 2. The product shall not be installed close to the switching power supply with an interval of ≥ 20cm to avoid the radiation interference of the switching power supply.
- 3. The installation height shall be  $\geq 1$  m from the floor to avoid shortening the remote control distance due to too weak reception signal.
- The product are not allowed to be close to or covered by metal objects, with an interval of ≥ 20cm to avoid signal attenuation and shorten remote control distance.
- 5. Avoid installation at the corner of the wall or the corner of the beam, with an interval of ≥ 20cm to avoid signal interference.